



wilson & bradley **kin ora**

400 / 450 / 500 / 600mm

1

x8

x4

x1

x4

x4

x2

Bin & tray will vary between models

Supplied components

Door Support Brackets

Not supplied with all models. If not supplied, skip step 13

2

L R

Use above template to mark holes

3

x8

2.5mm

Drill marked holes

4

x8

4.5mm

Attach both brackets

5

Align bottom of bracket with top of runner to measure location of mounting holes

6

Mount runner as per manufacturers instructions (runners and screws not supplied)

7

(=) (=)

(d) (d)

(c) (c)

(b) (b)

Measure the cabinet width (b), and the runner hole height (c), and spacing (d), mark on the door

8

(e) (e)

Measure the hole inset distance (e) and mark on the door

9

Mount door runner brackets to door and clip into the runners (screws not supplied)

10

Remove drawer assembly

11

Install drawer back panel (refer to runner instructions for panel size, screws not supplied)

12

Re-install drawer assembly and adjust door

13

x4

x4

x2

Attach door brackets if supplied

14

Install tray

15

x4

2.5mm

Center tray, mark and drill holes

16

x4

x4

4.5mm

Attach tray with stepped screws

17

Re-install drawer and insert metal lid

18

Insert bins in tray