



Pullboy WB



Montageanleitung / assembly Instructions

1.

Total installation height (=Y + 70mm)	
Bin	Z
8 L	325 mm
17 L	325 mm
26 L	470 mm
29 L	500 mm
42 L	535 mm
40 L	565 mm
32 L	570 mm

2.

Höchster Eimer mm Highest Bin mm		mind. Y mm
295	8 L	255
295	17 L	255
430	26 L	400
460	29 L	430
495	42 L	465
505	40 L	495
530	32 L	500

3.

Wandstärke 16mm ? wall thickness 16mm ?
Wandstärke 19mm ? wall thickness 19mm ?

4.

4x
4,8x9 DIN7981

5.

Maß A = Schrankbreite (mm) - 2x Wandstärke(mm) - 31mm
dimension A = cabinet width (mm) - 2x wall thickness(mm) - 31mm
z.B. / e.g. 500mm - 2x16mm - 31mm = 437mm

Maß H = Maß Y + FA (Frontaufschlag / Front overlay) + 15mm
z.B. / e.g. 255 + 12mm + 15mm = 282mm

6.

2x
Snap

7.

2 x
= Schrankbreite (in mm) - 175
= cabinet width (in mm) - 175

Anschraublöcher individuell nach Frontausführung wählbar
Screw holes individually selectable according to the front design

8.

2x

9.