



wilson & bradley **kiq ora**

1 Supplied components

2 Door Support Brackets

3 Use above template to mark holes

4 Drill marked holes

5 Attach both brackets

6 Align bottom of bracket with top of runner to measure location of mounting holes

7 Mount runner as per manufacturers instructions (runners and screws not supplied)

8 Measure the cabinet width (b), and the runner hole height (c), and spacing (d), mark on the door

9 Measure the hole inset distance (e) and mark on the door

10 Mount door runner brackets to door and clip into the runners (screws not supplied)

11 Remove drawer assembly

12 Install drawer back panel (refer to runner instructions for panel size, screws not supplied)

13 Re-install drawer assembly and adjust door

14 Attach door brackets above the runner edge with screws

15 Install tray

16 Center tray, mark and drill holes

17 Attach tray with stepped screws

18 Re-install drawer and insert metal lid

19 Insert bins in tray